





**A**ttendant  
User Guide



# GENERAL INFORMATION



The following should be considered when reviewing this user guide:

- ▶ This document provides instructions for functions most frequently performed by the attendant. Refer to the Multiline Telephone User Guide for additional information on telephone operation.
- ▶ All operational instructions assume Prime Line Pickup is assigned to internal dial tone, Ringing Line Preference is assigned and only a single tenant has been assigned in the system.
- ▶ All access codes listed are standard; some may vary based on system assignment.
- ▶ Access to many features is based on system assignments. Not all features may be available from your telephone.
- ▶ The telephone display provides useful call processing information such as trunk access, recall indication, feature confirmation, *etc.*

## DSS/BLF LED INDICATIONS

TELEPHONE STATUS	DSS/BLF STATUS
Idle	Unlit
In-Use	Steady Red
FWD All /DND	Flashing Red
Special Mode - FNC Activity ( <i>i.e.</i> programming, feature access)	Slow Flashing Red



---

## PLACING INTERNAL CALLS



- ▶ Lift handset
  - ▶ Dial station number
  - OR** Press **Feature Access Key** or **One Touch Key** programmed for Direct Station Selection
  - ▶ Voice announce after tone burst
  - OR** Wait for ringing call to be answered
- NOTE:** When calling a multiline telephone, dialing "1" after the station number will change ringing to voice or voice to ringing.*

## TRANSFERRING CALLS



### **USING MANUAL DIAL**

With a call in progress:

- ▶ Press **TRF**
- ▶ Dial station number
- ▶ Wait for answer
- ▶ Press **TRF**
- ▶ Replace handset

### **USING DIRECT STATION SELECTION (DSS)**

With a call in progress:

- ▶ Press programmed DSS
- ▶ Wait for answer
- ▶ Press **TRF**
- ▶ Replace handset

***NOTE 1:** When transferring CO/PBX calls, it is not necessary to wait for the called party to answer.*

***NOTE 2:** If the called station is busy, press **TRF** and replace handset to initiate a camp-on. An unanswered camp-on or ring transferred call will recall after a preprogrammed time interval.*

***NOTE 3:** To return to the original party, press flashing **Line Key**.*

***NOTE 4:** A **Feature Access Key** or **One Touch Key** may be assigned for **DSS**.*

### **USING INTERNAL LINE**

With a CO call in progress:

- ▶ Press **HOLD**
- ▶ Dial station number
- OR** Press programmed **DSS**
- ▶ Announce call indicating which **Line Key** is being transferred
- ▶ Replace handset

***NOTE 1:** Multiline telephone users can pick up a held **Line Key** at their convenience.*

***NOTE 2:** This operation is not applicable when transferring to a Single Line Telephone or to a multiline telephone that does not have an appearance of the outside line being transferred.*

## NIGHT TRANSFER

.....

### *SET/CANCEL USING PROGRAMMABLE KEY*

- ▶ Press programmed  
**Feature Access Key**  
or **One Touch Key**

### *SET/CANCEL USING ACCESS CODE*

- ▶ Press **FNC**
- ▶ Dial Night Transfer code **80**
- ▶ Press **FNC**

*NOTE 1: All display telephones will indicate "■" when in the night mode.*

## PAGING

.....▶

### *PAGING USING PROGRAMMABLE KEY*

- ▶ Lift handset
- ▶ Press programmed **Feature Access Key** or **One Touch Key**
- ▶ Page
- ▶ Wait for Meet-Me Answer or replace handset

### *PAGING VIA ACCESS CODE*

- ▶ Lift handset
- ▶ Dial Paging code:
  - Internal**
  - ▶ All Zones **70**
  - ▶ Zone A **71**
  - ▶ Zone B **72**
  - ▶ Zone C **73**
  - ▶ All Call **77**

**OR**

- External**
- ▶ External Paging **75**
- ▶ Page
- ▶ Wait for Meet-Me Answer or replace handset

## SYSTEM-WIDE CANCEL OPERATIONS

.....

- ▶ Press **FNC**
- ▶ Dial System-Wide Cancel code **88**
- ▶ Press **FNC**  
(cancels Callback Request, Do Not Disturb and Call Forward)

---

## PROGRAMMING SYSTEM SPEED DIAL

- ▶ Press **FNC**
- ▶ Press **LNR/SPD**
- ▶ Dial System Speed Dial Memory location **20~99**
- ▶ Dial trunk access code **i.e. 9**
- ▶ Dial telephone number to be stored (24 digits maximum)
- ▶ Press **FNC**

**NOTE:** Press **LNR/SPD** to insert a pause or **RECALL** to store a hookflash.

## CLOCK/CALENDAR SETTING

- ▶ Press **FNC**
- ▶ Dial **9 #**
- ▶ Enter hour and minute via dialpad
- ▶ Press **RECALL** to change AM/PM setting
- ▶ Press **HOLD** to change to calendar setting
- OR** Press **FNC** to exit this feature
- ▶ Press **RECALL** to select day of week
- ▶ Dial **#** to move the cursor to day of month field
- ▶ Enter day of month via dialpad
- ▶ Press **RECALL** to select month
- ▶ Dial **#** to move the cursor to year field
- ▶ Enter last two digits of year via dialpad
- ▶ Press **FNC**

**NOTE:** Dial\* to move cursor to the left.

## SYSTEM SPEED DIAL DIRECTORY

20	60
21	61
22	62
23	63
24	64
25	65
26	66
27	67
28	68
29	69
30	70
31	71
32	72
33	73
34	74
35	75
36	76
37	77
38	78
39	79
40	80
41	81
42	82
43	83
44	84
45	85
46	86
47	87
48	88
49	89
50	90
51	91
52	92
53	93
54	94
55	95
56	96
57	97
58	98
59	99

The material contained herein is subject to change without prior notice at the sole discretion of NEC America, Inc.

**NEC**

NEC America, Inc.  
(214) 518-5000  
©1994 NEC America, Inc.

**C&C** for Human Potential

7/96



722008